

XR 112 DRY IRON

1100 W | WHITE & SKY BLUE



XR 112 DRY IRON

Congratulations on your purchase and welcome to Billion Family!
You are now a proud owner of Billion 1100W Dry Iron.

Contents

1. General Product Description
2. Important Instructions
3. Using the Appliance
 - 3.1 Before first use
 - 3.2 Hints for Ironing
 - 3.3 Setting the temperature
 - 3.4 Ironing
 - 3.5 Storage
4. Cleaning & Maintenance
 - 4.1 Cleaning
 - 4.2 Environment
 - 4.3 Troubleshooting
5. Specifications, Warranty, Legal



1. GENERAL PRODUCT DESCRIPTION

**2 Layered Dupont Teflon
Classic Non-stick Coating**



Temperature dial (rotate)

Stress and Twist Reliever
& Cord winding clip

3- core cotton braided
Mains Cord

Temperature Ready
smart Feedback
Indicator

Rear side

Type plate

Soleplate



2. IMPORTANT INSTRUCTIONS

Read this user manual carefully before you use the appliance and save it for future references.

Danger

- Never immerse the iron in water.

Warning

- Check if the voltage indicated on the type plate corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the mains cord or the appliance itself shows visible damage, or if the appliance has been dropped.
- If the mains cord is damaged, you must have it replaced by Billion, a service center authorized by Billion or similarly qualified persons in order to avoid a hazard.
- Never leave the appliance unattended when it is connected to the mains.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Do not let the mains cord come into contact with the hot soleplate of the iron.

Caution

- Only connect the appliance to an earthed wall socket.
- Check the mains cord regularly for possible damage.
- Always place and use the iron on a stable, level and horizontal surface.
- The soleplate of the iron can become extremely hot and may cause burns if touched.
- When you have finished ironing, when you clean the appliance and also when you leave the iron even for a short while: put the iron on its heel and remove the mains plug from the wall socket.
- The appliance is intended for household use only.

Electromagnetic fields (EMF)

This Billion Appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and per the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

3. USING THE APPLIANCE

3.1 Before first use

- Unwind & straighten the power cord using Stress and Twist Reliever.
- Remove the soleplate sticker, if any.
- Connect the Iron to a suitable mains supply outlet.
- Turn the temperature control dial to desired textile setting, Amber SMART Feedback Indicator glows.
- SMART Feedback indicator turns “OFF” when the required temperature is reached.
- When switching ON Iron for the first time, there might be some emission of fumes. These fumes are caused due to burning of protective lubricants. It is not a product fault & will disappear after 1 or 2 heating cycles.
- Iron a damped towel for removing any protective chemical left on the sole plate. After a few minutes the Iron is ready for proper use.

3.2 Hints for Ironing

- Sort out the articles to be Ironed per the type of Fabric. This will minimize the frequency of temperature adjustment for different types of garments.
- Test Ironing a small area on the back side or inside the garment if you are unsure about the type of fabric. Start with a low temperature & increase gradually.
- Wait for about three minutes before Ironing heat sensitive fabrics. Temperature adjustment needs certain time to reach the required level, no matter it is higher or lower.
- Delicate fabrics such as silk, wool, velour etc. are best ironed with an ironing cloth to prevent shine marks.

3. USING THE APPLIANCE

3.3 Setting the temperature

- Put the Iron on its heel.
- To set the required ironing temperature, turn the temperature dial to appropriate position.
- Check laundry care label for the required ironing temperature (refer image to the right):
 - Single dot for synthetic fabrics (eg. Nylon, Rayon)
 - Two dots for Silk and wool
 - Three dots for Cotton and Linen
-
- If you don't know the type of fabric you're ironing, determine the right temperature by ironing the part that is not visible when you wear or use the fabric.
- For Silk, woolen & synthetic materials, iron the reverse side of the fabric to avoid shiny patches.
- Start ironing the clothes that require the lowest ironing temperature, such as those made of synthetic fibres.



3.4 Ironing

- Connect the Iron to recommended mains supply outlet.
- Turn the temperature control dial in clockwise direction, select kind of textile to be ironed against pointer
- Smart Feedback Indicator glows indicating the Iron is switched ON.
- Smart Feedback indicator turns OFF when the required temperature is reached.
- The Iron is ready for use. Iron the clothes
- Switch OFF the Iron after use.
- Disconnect the Iron from the mains supply outlet when it is not in use.
- When the Iron gets cooled completely, store it vertically in safe place as guided in next "Storage" section.

3.5 Storage

- Put the Iron on its heel.
- Remove the main plug from the wall socket & let the Iron cool down for atleast 30 minutes.
- Wind the mains cord around the heel's cord storage facility (as shown to the right)
- Secure the cord winder clip
- Store the Iron on its heel in a safe & dry place



4. CLEANING & MAINTENANCE

4.1 Cleaning the Iron

- Disconnect the Iron from the mains supply outlet.
- Use a dampened cloth or non-scratching cleaner to remove any deposits on the soleplate.
- Never use sharp & rough objects to remove the deposits on the soleplate
- Never use any abrasive, vinegar or descaling agents to clean the Iron.

4.2 Environment

- Do not dispose-off the appliance with the normal household waste, rather hand it over at an official collection point for recycling. By doing this, you help to preserve the environment.

4.3 Troubleshooting

- This section summarizes the most common problems you may encounter with the appliance. If you are unable to solve the problem with the information below, please contact the Consumer Care Centre.

Problem	Possible Cause	Solution
The iron is plugged in but the soleplate is cold	1. There is connection Problem	Check the mains cord the plug & the wall socket
	2. The temperature dial is set to MIN	Set the temperature dial to the required position (See section “Setting the temperature” in chapter “Using the appliance”)

5. SPECIFICATIONS

We recommend that all users read the following instructions carefully before using the appliance to ensure safe operation and long life.

- Model: Dry Iron XR112
- Mains Supply: 230V A.C.
- Wattage: 1100watts
- Soleplate: Dupont Teflon Classic coating, 2 layered non-stick coating
- Cord: ISI marked, 3 core cotton braided, 1.9 mts, 360° Swivel freedom with 3 pin plug
- Weight: 650 gms
- Handle: Comfortable Ergo-grip
- Cool touch Body
- Safety: ISI, IS: 366 Performance Testing & IS: 302 Safety Testing
- Temperature ready Smart Indicator
- Button groove
- Stress and Twist Reliever & Cord winding clip

WARRANTY DETAILS



Please refer to the separate warranty statement.

Customer Support

Customer care officer:

Email: cs@billion.com

+91 80 46331002

[9AM to 6PM on all working days]

Billion

LEGAL

Issue date: June 2017

Version: 1.1.0

© Flipkart India Pvt Ltd. All rights reserved

Billion is a registered trademark and property of Flipkart India Pvt Ltd.



Flipkart India Pvt Ltd, with registered office at 447C, Koramangala Industrial Layout Block 4, 12th Main, 1st A Cross Road, Bangalore - 560034.

Specifications are subject to change without notice due to continuous improvement programs.

**Billion offers a range of
Made for India products**

OnlyOnFlipkart

Billion

